

# MOUNTING INSTRUCTIONS FOR PANHARD KIT WITH HAIRPIN SET-UP!

**PETE JAKES**

HOT ROD PARTS

401 Legend Lane, Peculiar, MO 64078  
(816) 758-4504 Tech Line  
(816) 758-4512 Fax  
EMail: calkid@casstel.net

AFTER LOCATING POSITION,  
TACK, THEN WELD.

BRACKET

PANHARD BAR

#1010-HP

HAIRPIN BATWING

TIE ROD

AXLE

© PETE JAKES '09

## NOTE:

- 1- BEFORE INSTALING THE PANHARD BAR, ASSEMBLE THE FRONT END AND SET-UP FOR RIDE HEIGHT
- 2- ATTACH THE ADJUSTABLE ROD-END TO THE BATWING AS SHOWN.
- 3- ATTACH THE DRIVERS SIDE PANHARD BAR TO THE BRACKET, MEASURE OR SET TO PARALLEL TO THE TIE-ROD. 4- TACK BRACKET TO UNDER SIDE OF FRAME, CHECK AGAIN TO A PARALLEL DISTANCE TO THE TIE-ROD.
- 5- MAKE A "SNUG-UP" ADJUSTMENT ON THE BATWING SIDE. 6- ROD SHOULD HAVE NO BINDING, AND SHOULD BE CLEAR TO MOVE UP AND DOWN WITH FRONT-END RIDE
- 7- MAKE FINAL WELD TO THE BRACKET ON FRAME.

