

# PETE JAKES

HOT ROD PARTS

## # 5018

# 1935-'40 FORD TRIANGULATED INSTRUCTIONS

CENTER OF AXLE

BRACKET SHOULD LAY ABOUT 3/4" FROM TOP OF RAIL, ALLOW FOR PINION ADJUSTMENT WHEN YOU SET-UP!

SET BARS PARALLEL AS SHOWN

**NOTE:**  
VIPER-ALLOY  
COIL-OVER SHOCKS  
AND HARDWARE  
ARE OPTIONAL!

29 5/8"

SET THE TOP BAR PARALLEL TO THE BOTTOM BAR AND THIS WILL ALLOW TOP BRACKET TO FIND CORRECT POSITION FOR FINAL MOUNT

ALIGN 5" FROM CENTER OF HOUSING AS SHOWN

SET BARS PARALLEL  
SET BRACKET UP 1" UP FROM BOTTOM OF FRAME AND PARALLEL TO RAIL BOTTOM

**NOTE:**

TACK WELD ALL BRACKETS, THEN AGAIN CHECK FOR FINAL ALIGNMENT AND PLACEMENT BEFORE FINAL WELD!

