



Tech Line (816) 758-4504

**1936 CHEVY STANDARD  
MASTER CYLINDER MOUNT  
AND PEDAL KIT  
POWER & MANUAL**

5410A

**NOTE:** This kit will mount the pedal/booster to the side rail. Original crossmember must be removed for booster clearance. Pedal enters the floor through the original hole area. Will not fit convertible frames.

1. Remove original brake assembly.
2. Locate new mount over frame at the dimensions provided below.
3. Install pedal arm and check all clearances.
4. Mark and drill holes through the frame rail. Install bolts and tighten securely.
5. Install booster and/or master cylinder, install and adjust linkage.

