

6000 Steering box mount Instruction Sheet

Step 1- Install all three frame bolts loosely



Step 2- Then install two lower box bolts loosely



Step 3- Then tighten all bolts

