



1
CUT BRACKET AT
THE CENTER LINE...
... ALIGN BOTTOM ON
HOUSING AND TACK WELD.
AFTER ALIGNMENT IS
CORRECT, WELD BOTH SIDES
OF BRACKET TO HOUSING!

2
POSITION TOP OF BRACKET
ON HOUSING, TACK WELD,
CHECK YOUR ALIGNMENT,
WELD TO HOUSING
AS SHOWN!