


Instructions for #6005-6005A

'42-'48 FORD

SMALL BLOCK CHEVY MOTOR MOUNTS
FOR USE WITH ORIGINAL TYPE '58-'72 CHEVY RUBBER
INSULATOR MOUNTS OR PETE AND JAKE'S #82142





STEP #1

A STEEL DISC HAS BEEN PROVIDED WITH THIS KIT. IT MUST BE WELDED INTO HOLE IN STOCK FRAME BEHIND CROSSMEMBER TO SUPPORT MOTOR MOUNT GUSSET.

STEP #2

TO LOCATE MOTOR MOUNT, MEASURE $3 \frac{1}{4}$ " FROM CENTER OF CLOSEST CROSSMEMBER RIVET ON TOP OF FRAME TO FRONT FACE OF MOTOR MOUNT TUBE AS SHOWN.



STEP #3 (FOR USE WITH MECHANICAL FUEL PUMP)
#6005A MOTOR MOUNT KIT INCLUDES HARDWARE NECESSARY FOR NOTCHING PASSENGER SIDE OF CROSSMEMBER TO CLEAR MECHANICAL FUEL PUMP. MEASURE 2" FROM CROSSMEMBER EDGE AND MAKE A VERTICAL CUT PARALLEL TO FRAME RAIL. CUT SHOULD BE $1 \frac{1}{2}$ " DEEP. THEN CUT REMAINDER OF CROSSMEMBER TOWARD CENTER ON A LEVEL PLANE. WELD IN NEW PLATES (PROVIDED).